

=====
SECTION VII - SPECIAL PRECAUTIONS & SPILL/LEAK PROCEDURES

PRECAUTIONS: Medex should be stored under conditions which approximate end-use application; typically 65 - 80 degrees F, 30 - 80% RH; and should not be co-stored with materials which offgas formaldehyde.

WASTE DISPOSAL: Normally this material can be salvaged for use; otherwise incinerate or landfill in accordance with local, State and Federal regulations.

=====
SECTION VIII- SPECIAL PROTECTION INFORMATION

VENTILATION: High-efficiency wood dust removal and collection is necessary for woodworking operations.

RESPIRATORY PROTECTION: Meeting OSHA criteria if PEL is exceeded.

OTHER PROTECTIVE EQUIPMENT: Safety goggles are recommended during remanufacturing operations.

=====